

SPIN RECOVERY

- 1. VERIFY AILERONS NEUTRAL AND THROTTLE CLOSED.**
- 2. APPLY FULL OPPOSITE RUDDER.**
- 3. MOVE CONTROL WHEEL BRISKLY FORWARD TO BREAK STALL.**
- 4. NEUTRALIZE RUDDER AND RECOVER FROM DIVE.**

0405059-1