

152 AND AEROBAT CHECK LIST

BEFORE TAKE-OFF

Controls - - FREE AND CORRECT

Elevator trim - TAKE-OFF

Fuel valve - ON

Runup - COMPLETE

Carburetor heat, - OFF

Mixture - RICH

Flaps - 0° - 10°

Instruments - CHECK AND SET

Seats and belts - SECURE

BEFORE LANDING

Mixture - RICH

Carburetor heat - ON

Airspeed - 65 KTS FLAPS UP

60 KTS FLAPS DOWN

0405060-1