

**SHOULDER HARNESS MUST
BE WORN DURING TAKE-
OFF AND LANDING WITH
SEAT IN OUTBD POSITION,
SEAT BACK UPRIGHT AND
HEADREST FULLY EXTENDED**

101-384083-1