

INSTALL ON GARLOC

TURN C.W. UNTILL TOOL

STOPS REMOVE GARLOC

