	783			9	Control of the second	
1. Approving Civil Aviation Authority/Country:  FAA/United States	AUTHORIZED RELEASE CERTIFICATE  FAA Form 8130-3, AIRWORD MINESS APPROVAL TAG				3. Form Tracking Number: 20190007356987Y15 337834133 5. Work Order/Contract/Invoice Number: 7774983 337834124 Page 1 of 1	
23500 W 105th Street PR 28093L  Olathe KS 66061						
6.Item: 7. Description:	8. Part Number:		9. Quantity:	10. Serial Numb	per: 11. Status / Work:	
001 MST67A DIV BITE BT	066-01143-0601		1	4415	15 TESTED	
SEE ATTACHED DOCUMENTS AS AF CERTIFIES THAT THE WORK SPECIFIED IN BLC TO SERVICE UNDER EASA PART 145 APPROVA	OCK 11/12 WAS CARRIED OUT IN ACCORDANCE WIT	TH EASA PART 145 AND IN	RESPECT TO THAT	WORK THE COM	PONENT IS CONSIDERED READY FOR RELE	
13a. Cedifies the items identified above were  Approved design data and are  Non-approved design data spe	in a condition for safe operation.	Certifies that unles	12 was accomplis	ied in Block 12, t	Other regulation specified in Block 12 he work identified in Block 11 and nco win Title 14, Code of Federal tems are approved for return to service.	
13b. Authorized Signature:	13c. Approval/Authorization No.:	14b. Authorized S			14c. Approval/Certificate No.: PR2R093L	
13d. Name (Typed or Printed):	13e. Date(dd/mmm/yyyy):	14d. Name (Typed	,		14e. Date(dd/mmm/yyyy):	

User / Installer Responsibilities

It is important to understand that the existence of this document alone does not automatically constitute authority to install the aircraft engine/propeller/article. Where the user/installer performs work in accordance with the national regulations of an airworthiness authority offerent than the airworthiness authority of the country specified in Block1, it is essential that the user/installer ensures that his had airworthiness authority accepts aircraft engines/propeller(s/article) from the airworthiness authority specified in Block1, at its essential that the user/installer ensures that his had airworthiness authority accepts airworthiness authority specified in Block1, at the user/installer ensures that his had airworthiness authority specified in Block1, at the user/installer ensures that his had airworthiness authority accepts airworthiness authority specified in Block1. The Blocks is a manufacture and a property accepts airworthiness authority of the country specified in Block1, at the user/installer ensures that his had a property accepts a property accepts a property and a property accepts a property accepts a property and a property accepts a property